




Installation & Operation

40D Rotator (SELP-22809) with Hold Down and 180° Stop

This sheet describes the hydraulic connections required to properly install this unit. Operation of attachment functions is also described.

Hydraulic Hook-up



RR0274.ill

Part No. 6025605

cascade®
corporation

For Technical Support . . .

Call: 1-800-227-2233

OR

Write: Cascade Corporation, P.O. Box 20187, Portland, OR 97294

To Order Parts . . .

Call: 1-888-227-2233

OR

Write: Cascade Corporation, 2501 Sheridan Ave., Springfield, OH 45505

Attachment Functions

